



RS-232

CONCENTRADOR

# RED DE LECTORES

BUS CAN

001

002

051

052

101



NDCAN



DISPLAY



NDCAN MAX



TECLADO

NDCAN 16R



LECTOR  
MAGNETICO



LECTOR  
MOTORIZADO



LECTORES  
PROXIMIDAD



TERMINAL  
DE PARED



TAQUILLA 1, 2, 3, 4 ..... 15, 16